

















Lumens Visualiser Quick Guide

Top Menu

| Icon | Function Descriptions |
|---|---------------------------|
|  | Real-time image |
|  | Image browser page |
|  | Function settings page |
|  | Software information page |
|  | Switch to Full Screen |

Left Menu


















| Icon | Function Descriptions |
|---|---|
|  | Select the connection mode of camera |
|  | Turn on/off the Document Camera (does not support USB models) |
|  | Auto focus |
|  | Freeze |
|  | Capture |
|  | Time Lapse |
|  | Setting of annotation tool |
|  | Eraser (Clear all the objects) |
|  | Recover |
|  | Redo |

Lumens Visualiser Quick Guide

Right Menu



| Icon | Function Descriptions |
|---|---|
|  | Switch function menus |
|  | Image setting |
|  | Lamp On/Off |
|  | Zooming in/out the image |
|  | Brightness |
|  | Recording; this function is not supported in Wireless mode and Share Image mode |
|  | Free-hand drawing tool |
|  | Arrow |
|  | Circling tool |
|  | Eraser |
|  | Draw a rectangle |
|  | Draw a line |
|  | Edit text |
|  | Mask Mode |
|  | Spotlight Mode |