
















Lumens Visualiser Quick Guide

Top Menu

Icon	Function Descriptions
	Real-time image
	Image browser page
	Function settings page
	Software information page
	Switch to Full Screen

Left Menu


















Icon	Function Descriptions
	Select the connection mode of camera
	Turn on/off the Document Camera (does not support USB models)
	Auto focus
	Freeze
	Capture
	Time Lapse
	Setting of annotation tool
	Eraser (Clear all the objects)
	Recover
	Redo

Lumens Visualiser Quick Guide

Right Menu



Icon	Function Descriptions
	Switch function menus
	Image setting
	Lamp On/Off
	Zooming in/out the image
	Brightness
	Recording; this function is not supported in Wireless mode and Share Image mode
	Free-hand drawing tool
	Arrow
	Circling tool
	Eraser
	Draw a rectangle
	Draw a line
	Edit text
	Mask Mode
	Spotlight Mode